

Free-standing Desk Screen assembly instructions - Type 1

- 1: Unroll the film from the top rail.
- 2: Push the corner bracket into each end of the side rails (as shown).
- 3: Push the side rail brackets into the top and bottom rails, ensuring the film sits correctly in the side rails. The side rails will sit between the top and bottom rails.
- 4: Place the assembled screen into the feet and tighten the wing bolts until the bottom rail is lightly gripped.

Your Desk Screen is now ready for use!

NOTE: When the screen is first assembled, the film may be creased due to being rolled up. However this will flatten out within 2-3 days.

