

# PORTLAND CANTILEVER ASSEMBLY INSTRUCTION

|                |                |           |              |                  |                  |                  |             |
|----------------|----------------|-----------|--------------|------------------|------------------|------------------|-------------|
| 1              |                | 2         |              | 3                |                  |                  |             |
|                |                |           |              |                  |                  |                  |             |
| ① SEAT CUSHION | ② BACK CUSHION | ③ ARMREST | ④ CANTI BASE | ⑤ SCREW<br>M6*25 | ⑥ SCREW<br>M6*30 | ⑦ SCREW<br>M6*40 | ⑧ ALLEN KEY |
|                |                |           |              |                  |                  |                  |             |
| 1 PC           | 1 PC           | 1 PAIR    | 1 PC         | 4 PCS            | 4 PCS            | 6 PCS            | 1 PC        |

IMPORTANT NOTE - PLEASE ASSES ALL COMPONENTS PRIOR TO DISPOSAL OF PACKAGING AND ASSEMBLY OF CHAIR