

Laptop AC Adapter Mini 100W Quick guide

135-73 / 135-74





www.sandberg.it

Quick guide

Disclaimer:


The use of this product is entirely at the consumer's own risk. Sandberg A/S, its dealers and distributors cannot be held liable for any damage to connected equipment, loss of data, etc.

Attention!

- Do not open or repair this device.
- Disconnect the power plug from the mains supply before cleaning the device. Do not clean the device with a liquid cleaner or a spray.
- Keep this device away from liquids, such as water.
- Do not use this device in a damp environment.
- This device must be connected to a cut-off switch.

This device is for indoor use only. Temperature: 0 degress C to 40 degrees C. Humidity: 20% to 80 %.

Quick guide



Compatible Model

FOR HP: 18.5V3.5A, 19.5V3.33A, 19V4.74A
FOR SONY: 19.5V3.33A, 19.5V3.9A, 19.5V4.7A
FOR SAMSUNG: 19V2.1A, 19V3.16A, 19V4.22A, 19V4.74A
FOR TOSHIBA/LENOVO/ASUS: 19V3.42A, 19V3.95A, 19V4.74A, 20V3.25A,20V4.5A
FOR ACER: 19V3.42A, 19V4.74A
FOR DELL: 19.5V3.34A, 19.5V4.62A
FOR HP: 19.5V3.33A,19.5V4.62A
FOR LENOVO: 20V3.25A, 20V4.5A
FOR DELL: 19.5V3.34A, 19.5V4.62A
FOR LENOVO IBM: 20V2.25A, 20V3.25A, 20V4.5A
FOR HP: 18.5V3.5A,19V4.74A,19.5V3.33A

Quick guide




Check the specification and dimensions of your laptop's power DC connector.




Pick the corresponding DC connector for your laptop.

Quick guide



Connect the DC connector.

Quick guide





Quick guide



Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.it/warranty.





For information on handling electronic waste, see www.sandberg.it/weee