



Warning! Read instructions before using the machine





Kit - A21A / Kit AA12





Charles



WV 370 WV 380 WV 470










Wet - Using your machine





























CVC 370 WV 370 WV 380



NVM-2BH 604016

WV 470



NVM-3AH 604018









Fitting the Face on



Removing the Face





About your machine

- Voltage Frequency
- Power rating
- 3 Weight (ready to use)
- 4 Company Name & Address
- Machine Description
- 6 Machine yr/wk Serial number
- WEEE Logo
- 8 Class 2 Symbol
- O CE Mark



PPE (personal protective equipment) That may be required for certain operations.

















Ear Protection

Safety Footwear

Safety Gloves

Clothing Protection



NOTE: A risk assessment should be conducted to determine which PPE should be worn.

Safety Critical Components

Mains leads:

HO5-V2V2-F

10 x 2 x 1 00 mm²

WEEE Legislation

(Waste, Electrical and Electronic Equipment)

Vacuum cleaner, accessories and packaging should be sorted for enviromental-Friendly recycling.

(Only for EU Countries)

Do not dispose of vacuum cleaner into household waste! According to the European Directive 2002 / 96 / EC on waste electrical and electronic equipment and its incorporation into national law.

Vacuum cleaners that are no longer suitable for use must be separately collected and sent for recovery in an environmental-friendly manner.



Failure to rectify the problem or in the event of a breakdown contact your Numatic dealer or the Numatic Technical helpline +44 (0)1460 269268

Information for Wet & DRY Use Vacuum cleaners



Read the instruction manual before using the machine.

Operators shall be adequately instructed on the use of these machines.

As with all electrical equipment, care and attention must be exercised at all times during use, in addition to ensuring that routine and preventative maintenance is carried out periodically to ensure safe operation.

Failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer can accept no responsibility

in this respect.

The machine shall be disconnected from the mains by removing the plug from the supply socket during cleaning or maintenance and when replacing parts or converting the machine to another function.

The machine is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction.

Children being supervised are NOT to play with the machine.

This appliance is intended to be assembled, cleaned and maintained by an adult.

This machine is not a toy.



If foam/liquid comes out of machine exhaust, switch off immediately. Allow the accumulated liquid to drain out through the machine exhaust, check the float assembly to ensure correct operation, empty the container if full of liquid, reassemble the machine. Immediately upon start up there will be a certain amount of liquid issuing from the machine exhaust which will be the residue of liquid still within the power head. This will be quickly discharged after which the machine should function normally.

Liquid ejected from the machine could be hazardous as a result of its temperature, pressure or

chemical content.

This machine is not suitable for the collection of biological hazards, hazardous or explosive dust. You should contact your local distributor if you require a machine capable of performing these tasks.

Ensure that the filtration system fitted to the machine is suitable for the material being collected.

This machine is for indoor use only.

This machine shall be stored indoors only

This product complies with the requirements IEC 60335 -2.69.

When moving from one place to another, consider the weight of the machine.

NOTES

This machine is also suitable for commercial use, for example in hotels, schools, hospitals, factories, shops and offices for other than normal housekeeping purposes.



- Use a bag and filter at all times when using 'dry'.
- Keep your machine clean.
- Keep filters clean.
- Regularly clean the water level limiting float safety valve and examine

for signs of damage or correct operation.

- Keep hoses and tubes clear.
- Replace any worn or damaged parts immediately.
- Regularly examine the power cord, if damage is found, power cord must be replaced by a qualified person using the correct Numatic original part.
- Empty dust container frequently.
- Keep diffuser filter (where fitted) clean.



DON'T

- Use steam cleaners or pressure washers to clean the machine or use the machine in the rain.
- Immerse in water for cleaning.
- Allow any inexperienced repairs. Call the experts.
- Use wet if float valve is not functioning or fitted.
 Use to suck up hot ashes, or lighted cigarette ends.
- Suck up liquid before emptying dirt from container.
- Suck up dirt before emptying liquid from container.
- Run the machine over the power cable during operation as a hazard may occur.
- Pull on the cable to unplug the machine from the power supply.
- Walk over-wet carpets, upholstery or fabrics.
- Walk on clean carpets until fully dry.
- Sprav onto people or animals.
- Attempt machine maintenance or cleaning unless the power supply plus has been removed from the supply outlet.

Fault Finding

This machine can be used for wet and dry pick up.

Dry Mode

If the vacuum cleaner stops working switch off and remove the plug from the wall before investigating were the fault lies.

If the vacuum cleaner will not pick up any debris from the surface, switch off and remove the plug from the wall, inspect the floor tool, wands and hose for blockages, if no blockages are found, the dust bag may be full if the dust bag is not full the filter may be blocked.

Wet Mode

If the vacuum cleaner stops working switch off and remove the plug from the wall before investigating were the fault lies.

If the vacuum cleaner has a blockage and will not pick up liquid, switch off and remove the plug from the wall, has the float valve operated, this will shut off the suction and the pitch of the vacuum motor will change Remove the power head and empty the liquid out of the container, if the container is empty, check that the floor tool wands and hose are not blocked.

After use always inspect the machine for damage.

Data

	Motor	AirFlo	Suction	Cleaning Range	Class
CVC 370	1200W	40 L/sec	2500 mm	28.8m	II
WV 370	1200W	40 L/sec	2500 mm	28.8m	
WV 470	1200W	40 L/sec	2500 mm	28.8m	
	Capacity Dry	Capacity Wet	Size	Weight	Sound Pressure
CVC 370	15 Ltrs	9 Ltrs	355x355x510	7.1 Kgs	73-77 dB
WV 370	15 Ltrs	9 Ltrs	355x355x510	7.1 Kgs	(IEC 60704-2-1)
WV 470	27 Ltrs	20 Ltrs	355x355x710	9.6 Kgs	Uncertianty: 0.2 dB (A)

Failure to rectify the problem or in the event of a breakdown contact your Numatic dealer or the Numatic Technical Helpline +44 (0)1460 269268
Wenn Sie das Problem nicht beheben können oder wenn es zu einer Störung kommt, wenden Sie sich an Ihren Numatic-Händler oder rufen Sie bei der Numatic Technical Helpline an unter 0049 (0)511 9842160.
Si vous ne parvenez pas résoudre le problème ou en cas de panne, contactez votre revendeur Numatic ou le service d'assistance technique Numatic au +33164726161
Neem contact op met uw Numatic-verdeler als u het probleem niet kunt verhelpen of de machine dienst weigert. U kunt ook de technische hulplijn van Numatic bellen op +31 172 467 999
Failure to rectify the problem or in the event of a breakdown contact your Numatic dealer or the Numatic Technical Helpline 0861 686 284



Numatic International Limited warrant to the original purchaser that its products are free of defects in both material or workmanship for the period shown below:-

Homecare and Cleancare Vacuum cleaners	
Rotary Floor Machines	2 Years
Twintec Auto Scrubber Dryer	. 1 Year
Vario Ride-On Scrubber Dryer	00 hours
Mopping, Compacts, Combi and Servocare Products	1 Year
Individual Accessories and Spare Parts	6 Months

Note: This warranty expressly excludes consumable parts such as carbon brushes, floor brushes, mops, batteries etc, that are considered replaceable from time to time during the normal working life of the machine.

- A. The warranty period commences from the date the goods are purchased.
- B. All warranty claims must be processed through the Dealer from whom the equipment was purchased. The Dealer will co-operate with the purchaser throughout the warranty claims procedure and will arrange any necessary repairs using genuine Numatic parts.
- C. If the original Dealer is no longer able to fulfil his obligations please contact Numatic International Limited with full details of the claim and proof of purchase so that this may be processed without delay.
- D. Any warranty claim can only relate to the specific part that is proven to be at fault and for which a replacement will be supplied but cannot be extended to constitute a claim against the complete machine.
- E. Numatic International will supply the Dealer with any warranty parts required, subject to the claim being validated, after return of the faulty items in accordance with Numatic International Limited's General Conditions of Sale.
- F. Claims will not be accepted if they are the result of fair wear and tear, misuse or abuse of any kind.
- G. No replacement will be given unless the appropriate evidence of the validity of the claim has been provided to the satisfaction of Numatic International Limited.
- H. Numatic International Limited reserve the right to charge for any unnecessary work carried out as a result of an invalid claim.
- I. No variation to this warranty may be made or implied by any member of Numatic International Limited or its Dealers unless such variation is in writing and authorised by the Company



umatic International Limited. Chard, Somerset, TA20 2Gt Telephone: 01460 68600 Fax: 01460 68458



EU DECLARATION OF CONFORMITY

We hereby declare under our sole responsibility that the following equipment fulfils all the relevant provisions of the following EU Directives:

Machinery Directive 2006/42/EC EMC Directive 2004/108/EC RoHS Directive 2011/65/EU

Machine Description:

Vacuum Cleaner

Type: CVC, WV, WX series

Manufactured by:

Numatic International Limited

Relevant standards upon which conformity is declared include:

IEC60335-1:1991+A1+A2 IEC60335-2-2:1993+A1+A2 IEC60335-2-69:1997+A1

EN 55014-1 2001 +A1 2001, +A2 2002 EN 55014-2 1997 + A1 2001 (Cat II)

EN 50366 2003 + A1 2006

A technical construction file for this equipment is retained at the manufacturer's address under the authorisation of the following signatory:

Name:Allyn Boyes

Position: Technical Manager

Signed:



Date: 01 /01/2013

Numatic International Limited,


Chard , Somerset. TA20 2GB

www.numatic.co.uk

GB

Wiring Diagram

12" Plastic WV / CVC WD-0239 (A02)



Machine Spare Parts



588256 CVC 370 Head



588255 WV 370 Head



588261 WV 470 Head



500816 370 Blue Drum



500081 Blue 380 Drum



500362 470 Blue Drum



204111 370 Castor



380 Castor 628485



204071 470 Rear Wheel



204111 470 Castor



370 Rear Wheel 227640 Rear Wheel 227868 Wheel Hub 219105 Fixing Screw

229777

Blue Trim



500694 370 Blue Drum



604165 Tritex Filter



U

502036 CVC / WV Float Cage



Re - Order 370 /380 Drum Hepaflo Bags Pack of 10 NVM-2BH 604016



Re - Order 470 Drum Hepaflo Bags Pack of 10 NVM-3AH 604018



Numatic International Limited, Chard, Somerset, TA20 2GB, ENGLAND. Telephone 01460 68600 Fax: 01460 68458 **www. nur.**

www. numatic.co.uk