


MODEL: 6984 Piano UK331A

BACK SEAT CASTERS (4)x1 (L)x1 (R) (5)x1 (6)x1 LARM LEFT ARM RARM RIGHT ARM (7)x1 (A)x4 (B)x4 (B)x4 (C)x8 (C)x8 (C)x8 (A)x4 (C)x8 (B)x4 (C)x8 (B)x4 (C)x8	(1)x1	(2)x1	(3)x5
(4)x1 (L)x1 (R) (5)x1 (6)x1 LARM LEFT ARM RARM RIGHT ARM GAS LIFT BASE (7)x1 (A)x4 (B)x4 (B)x4 (B)x4 (C)x1 (C)x2 (C)x2 (C)x3 (C)x4 (C)x4			
LARM LEFT ARM RARM RIGHT ARM (A)x4 (B)x4 (B)x4 (B)x4 (B)x4 (C) M8*22 MECHANISM SCREW	BACK	SEAT	CASTERS
LARM LEFT ARM RARM RIGHT ARM (7)x1 (A)x4 (B)x4 (B)x4 (B)x4 (B)x4 (C) (B)x4 (C) (C) (C) (C) (C) (C) (C) (C	(4)x1 (L)x1 (R)	(5)x1	(6)x1
(A)x4 (HIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII			
(A)x4 (H) M8*22 MECHANISM SCREW (B)x4 (H) M8*30 L-BAR SCREW		GAS LIFT	BASE
MECHANISM		(B)×4	

Teknik Office Ltd, West One 63-67 Bromham Road, Bedford, MK40 2FG
TEL:01234 328804 FAX:01234 342446

If you encounter any problems with the operation of your chair, please refer to the downloads section of our web site - www.teknikoffice.co.uk



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.



