
HUAWEI WATCH GT

HUAWEI WATCH GT Online Help-(01,en)

Issue 01

Date 2019-02-28





Contents

1 Getting started	
1.1 Using your HUAWEI WATCH GT	1
1.2 Wearing your watch	1
1.3 Screen control	2
1.4 Pairing your watch with your phone	5
1.5 Setting the time zone and language	6
1.6 Charging your watch	
1.7 Powering on and off/Restarting your band	9
2 Basic operations	12
2.1 Adjusting screen brightness	12
2.2 Locking and unlocking your watch screen	12
2.3 Weather reports	14
3 Fitness and health	16
3.1 Daily activity records	16
3.2 Starting a workout	17
3.3 Workout status	19
3.4 Heart rate monitoring	19
3.5 Sleep tracking	21
3.6 Syncing and sharing your fitness and health data	22
4 Messaging assistant	2 3
4.1 Incoming call notification	23
4.2 Rejecting an incoming call	23
4.3 Messages reminders and content display	23
4.4 Deleting a message	24
5 Setting alarms	26
5.1 Setting a Smart alarm	26
5.2 Setting an Event alarm	27
6 Watch faces	29
6.1 Changing the watch face	29
7 Apps	31

7.1 Barometer	31
7.2 Compass	32
7.3 Stopwatch and Timer	32
7.4 Flashlight	33
7.5 Find phone	33
8 Updating and factory reset	34
8.1 Viewing version information	34
8.2 Updating your watch and the Huawei Health app	34
8.3 Resetting your watch	36
8.4 Force restart	37
8.5 Viewing the Bluetooth name and MAC address	38
9 Maintenance	40
9.1 Water and dust resistance	40
9.2 Cleaning and care	41
9.3 Adjusting or replacing the strap	41
10 FAQs	4 3
10.1 How do I extend the standby time of my watch	43
10.2 Why is the step count between the Huawei Health app and my watch inconsistent	43
10.3 Which factors can affect heart rate monitoring	44
10.4 What should I do if the exercise data on my watch can't be synced to the Huawei Health app	44
10.5 What should I do if I can't sync sleep data to the Huawei Health app	45

1 Getting started

1.1 Using your HUAWEI WATCH GT

HUAWEI WATCH GT (hereinafter referred to as "watch") is a lightweight and fashionable smart watch with long battery life. It is designed to help you learn more about your health and provide professional workout guidance, and includes useful features such as workout monitoring, message notifications, heart rate monitoring, and GPS.

HUAWEI WATCH GT features a beautiful double crown design housing a colour screen and comes with an allergy tested strap for maximum comfort and safety. HUAWEI offers a range of strap designs so you can easily find one that suits you.

To start using the watch, wear it on your wrist and pair it with your phone using the Huawei Health app. You will then be able to enable various features, such as professional workout, heart rate monitoring, sleep tracking, and message alerts.

Professional workout

Optimise your workouts with a customised training plan and professional fitness advice.

• Heart rate monitoring

Keep track of your fitness and health with constant and accurate heart rate monitoring.

• Sleep tracking

Get better rest with the help of in-depth sleep pattern analysis.

• Instant notifications

Stay updated with notifications for messages, chat, social media, and more.

1.2 Wearing your watch

Wear your watch as per the figure below, making sure it fits comfortably around your wrist. Heart rate monitoring may be affected if you wear your watch too tightly or loosely.



The watch strap adopts a T-buckle design so it will not fall out easily. To wear the watch, insert one end of the strap into the T-buckle and fasten it.




MANOTE

- Your watch uses non-toxic materials which are not harmful to the body. If you have an allergic reaction, please consult a doctor immediately.
- Be sure to wear your band properly to maximise comfort.

1.3 Screen control

The watch features an AMOLED touchscreen. You can touch, touch and hold, or swipe on its screen.



Up button

Operation	Function	Remarks
Press	 Wake watch screen when the screen is off. Access the app list screen from the home screen. Return to the home screen. 	Not available in special scenarios such as calls and workouts.
Hold	 Power on your watch when the watch is off. Access the restart/power off screen when the watch is on. 	

Down button

Operation	Function	Remarks
Press	Open workout apps	Not available in special scenarios such as calls and workouts.
Hold	Lock/Unlock the screen	

Button functions during a workout

Operation	Function
Press the up button	Pause/Continue the workout
Press the down button	Switch screen
Hold the up button	End the workout

Operation	Function
Hold the down button	Lock/Unlock the screen
Swipe up or down on the screen	Switch screen
Touch and hold the screen	Replace data

Gestures

Operation	Function
Touch	Select and confirm
Touch and hold the home screen	Change watch face
Swipe up on the home screen	View notifications
Swipe down on the home screen	View shortcut menu
Swipe right or left	View your heart rate data, workout data, and weather information
Swipe right	Return to the previous screen


Wake the screen

To wake your watch's screen, you can do any of the following:

- Press the up button.
- Raise or rotate your wrist inward.
- Swipe down on the home screen to open the shortcut menu. Enable **Show time** and the screen will stay on 5 minutes.

M NOTE

You can enable the Raise wrist to wake screen function in the Huawei Health app.



Turn off the screen

- Lower or rotate your wrist outwards to turn off the watch screen.
- The screen will turn off automatically when the watch is idle for 10 seconds.

1.4 Pairing your watch with your phone

Hold the up button to turn on your watch. The watch is now ready to be paired via Bluetooth.

• For Android users:

- a. Download the Huawei Health app from the Google Play Store. (On Huawei phones, you can download the Huawei Health app from the AppGallery.) If you have already installed the Huawei Health app on your phone, make sure that it is updated to the latest version.
- b. Open the Huawei Health app and follow the onscreen instructions to set it up. Then, go to Me > My devices > Add > Smart Watch and touch HUAWEI WATCH GT.
- c. Touch Pair. The Huawei Health app will search for the watch automatically. Select HUAWEI WATCH GT-XXX from the list of devices. The watch will start to pair with your phone automatically.

d. When a pairing request appears on your watch screen, touch the request on your phone to complete the pairing.





For iOS users:

- a. Download the Huawei Health app from the App Store. If you have already installed the Huawei Health app on your phone, make sure that is updated to the latest version.
- b. Open the Huawei Health app. Access the **Device** screen, and touch the + icon in the top-right corner. Touch **Smart Watch** and select **HUAWEI WATCH GT**.
- c. Touch Pair. The Huawei Health app will search for the watch automatically. Select HUAWEI WATCH GT-XXX from the list of devices. The watch will start to pair with your phone automatically.
- d. When a pairing request appears on your watch screen, touch the pairing.

∭ NOTE

- Your watch screen will display an icon to inform you if pairing is successful, and start to sync information (such as date and time) from your phone.
- Your watch screen will display an icon to inform you if pairing has failed, then return to the startup screen.

1.5 Setting the time zone and language

The time zone and language settings on your phone will be automatically synced to your watch.

If you change the language, region, time, or time format on your phone, these changes will be automatically synced to your watch.


1.6 Charging your watch

Charging

Your watch comes with a magnetic charging cradle and a USB cable, which can be used with a HUAWEI charger to charge your watch. Connect the charging cradle to the charger using the USB cable. Place your watch onto the charging cradle. Align and attach the charging port to the magnets of the charging cradle. You should see the battery level on the watch face.

MOTE

- Before charging, make sure the charging port is clean and dry.
- Use the original charging cable that comes with the watch.
- Use an original HUAWEI charger (5 V/1 A or higher) or your computer's USB port to charge your
 watch. Using other chargers may result in issues such as slow charging speed or overheating. It is
 recommended that you purchase original HUAWEI chargers from an official Huawei store.



Charging time

It takes about 2 hours to fully charge your watch. When your watch is fully charged, **100%** will be displayed on the watch screen. Remove your watch from the charging cradle once it is fully charged.



M NOTE

- Charge your watch in a dry and well-ventilated environment.
- Before charging, make sure the charging port is clean and dry to prevent short circuits or other issues.
- To maximise the battery's lifespan, charging current will be reduced if the surrounding temperature is low. In this case, it may take a longer time to charge your watch.

Viewing the battery level


Use one of the following three methods to view the battery level:

Method 1: When your watch is charging, the battery level will be displayed on the charging screen. Press the up button to exit the charging screen.



Method 2: Swipe down on the watch's home screen. You can view the battery level in the shortcut menu.

Method 3: View the battery level in the Huawei Health app.



1.7 Powering on and off/Restarting your band

Powering on your watch

- **Method 1:** Hold the up button until the watch screen turns on.
- **Method 2:** Charge your watch and it will automatically power on.
- **□** NOTE

If you power on the watch when the battery level is very low, the watch will notify you and advise you to charge your watch. The watch's screen will turn off after 2 seconds, and you will be unable to power it on until you charge it.

Powering off your watch

- **Method 1:** Hold the up button and touch **Power off**.
- Method 2: Press the up button and go to Settings > System > Power off.
- When your watch's battery level is very low, it will vibrate to notify you and automatically power off.



Restarting your watch

- Method 1: Press and hold the up button and touch Restart.
- Method 2: Press the up button and go to Settings > System > Restart.



Basic operations

2.1 Adjusting screen brightness

On the watch home screen, press the up button, go to **Settings** > **Display** > **Brightness** to adjust screen brightness. Brightness is set to **Auto** by default, which automatically adjusts screen brightness based on your environment. Level 5 is the brightest and Level 1 is the dimmest setting.



2.2 Locking and unlocking your watch screen

Touch gestures will not work when your watch screen is locked. This feature is useful for preventing unintended operations (e.g. by water when you are swimming).

Lock the screen

Method 1: On the watch home screen, hold the down button.



Method 2: Swipe down from the home screen of your watch and touch Lock.

Unlock the screen

To unlock the screen, hold the down button for 5 seconds.



2.3 Weather reports

You can view the weather information for your current location on your watch.

Method 1: Use the Weather watch face

Use the Weather watch face to view the latest weather information on the home screen.

Method 2: Use the weather card screen

Swipe right on the home screen to access the weather card screen to view information such as current location, current weather, temperature, and air quality.

Method 3: Use the Weather app

On the home screen, press the up button, swipe up or down on the screen, and touch **Weather** to view information such as current location, current weather, temperature, and air quality.

Щ NOTE

- To use the weather report feature, enable **Weather reports** in the Huawei Health app.
- The weather information displayed on your watch comes from the Huawei Health app, and may differ slightly from that displayed on your phone since the Huawei Health app and your phone obtain weather information from different service providers.

• Ensure that both GPS and the Huawei Health app of your phone have permission to acquire location information. For best results, select **Use GPS**, **WLAN**, **and mobile networks** as the positioning mode instead of **Use GPS only**.

3 Fitness and health

3.1 Daily activity records

Using its acceleration sensor and a gyroscope sensor, your watch can detect and monitor your daily activities, including your step count, calories burnt, activity intensity, and the amount of time you have spent standing.

Your watch can automatically identify your current activity, such as whether you are walking, running, sleeping, or stationary.

Your band will record your activity data automatically, including your step count, workout distance, workout time, and calories burnt after identifying whether you are walking or running.

To view your fitness data after a workout, use either of these two methods:

Method 1: View your fitness data on your band

Press the up button, swipe up or down on the screen, and touch **Activity records**. Swipe up or down on the screen to view your calories burnt, workout distance, step count, and duration of moderate to high intensity activity.



Method 2: View your fitness data through the Huawei Health app.

View your fitness data on the Home screen in the Huawei Health app.

Ⅲ NOTE

To view your fitness data in the Huawei Health app, ensure that your watch is connected to your phone via the Huawei Health app.

3.2 Starting a workout

Your watch supports several workout types, including Running Courses, Outdoor Run, Indoor Run, Outdoor Walk, Climb, Trail Run, Outdoor Cycle, Indoor Cycle, Pool swim, Open water, Triathlon, and Other.



Starting Guided running

The watch provides you with professional running training courses from primary to advanced levels. These training courses provide a customised real-time running guide during a workout. You can select different courses during a workout, and can sync more courses from the Huawei Health app to the watch.

- 1. To start Guided running, press the up button, swipe up or down on the screen, go to **Workout** > **Running Courses**, and select a running course.
- 2. During the workout, press the up button to pause or end the workout. Press the down button to switch screens and view workout data.
- 3. After the workout, touch **Workout records** on the watch screen to view detailed workout data, including Training effects, General, Speed, Steps, Total height, Heart rate, Heart rate zones, Cadence, Pace, and VO2max.

M NOTE

You can also view detailed workout data on the Exercise records card in the Huawei Health app.

Starting a workout

- 1. Press the up button, swipe up or down on the screen and touch **Workout**.
- Swipe up or down on the screen to select a workout type. (Outdoor Run, Indoor Run, Outdoor Walk, Climb, Trail Run, Outdoor Cycle, Indoor Cycle, Pool swim, Open water, Triathlon, and Other.) Before a workout, you are able to set the target, reminders, and display screen on your watch screen.
- 3. To start the workout, touch the start icon on the watch screen.
- 4. During the workout, press the up button to pause or end the workout. Press the down button to switch between screens and view workout data.

5.	After the workout, touch Workout records on the watch screen to view detailed
	workout data.
	NOTE
	• If the workout distance or duration is too short, your watch will not record workout data.
	• Touch the end icon after a workout ends to prolong battery life.

3.3 Workout status

Training status lets you know how effective your training is by analysing your fitness level changes and training load for the past week, and assigning one of the following statuses: **Recovery, Productive, Peaking, Unproductive, or Detraining.** It also provides advice for the next stage of training.

You can also view your total workout load for the past week on the training load screen. Training load is classified as **High**, **Low**, or **Optimal**.

Press the up button, swipe on the screen to enter the **Workout status** screen, then swipe up on the screen to view your training status.

M NOTE

To view your training status, you need to have workout records for at least one week.

3.4 Heart rate monitoring

Your watch includes an optical heart rate sensor, which can continuously monitor and record your heart rate throughout the day to help you keep track of your health and fitness. To use this feature, enable **Automatically measure heart rate** in the Huawei Health app.

Heart rate measurement

- Wear your watch while keeping still.
- 2. To measure your heart rate, press the up button, swipe up or down, and touch **Heart** rate.



NOTE

To ensure accurate heart rate measurement, wear the watch normally and ensure the strap is securely fastened. Make sure that the watch contacts your skin directly without any obstructions.

Heart rate measurement during a workout

During a workout, your watch can display your real-time heart rate and heart rate interval, and notify you when your heart rate exceeds the upper limit. For best training results, you are advised to choose a workout based on your heart rate interval.

• Setting the heart rate interval calculation method

The heart rate interval can be calculated based on maximum heart rate percentage or HRR percentage. To set the heart rate interval calculation method, open the Huawei Health app, go to Me > Settings > Heart rate interval and warning > Calculation method, and select either Maximum heart rate percentage or HRR percentage.

MOTE

- If you select **Maximum heart rate percentage** as the calculation method, the heart rate interval for different types of workout activities (Extreme, Anaerobic, Aerobic, Fat-burning, and Warm-up) is calculated based on your maximum heart rate ("220 your age" by default). Heart rate = Maximum heart rate x Maximum heart rate percentage
- If you select HRR percentage as the calculation method, the heart rate interval for different types of workout activities (Advanced anaerobic, Basic anaerobic, Lactic acid, Advanced aerobic, and Basic aerobic) is calculated based on your heart rate reserve (HRmax HRrest). Heart rate = Heart rate reserve x Heart rate reserve percentage + Resting heart rate.
- The heart rate zone calculation method for a running course is not affected by the Huawei Health
 app settings. It is calculated based on Heart Rate Reserve (HRR) percentage for most running
 courses.
- Measuring your heart rate during a workout
- 1. After you start a workout, swipe on the watch screen to check your real-time heart rate and heart rate interval.

- 2. After your workout ends, you can check your average heart rate, maximum heart rate, and heart rate interval under **Workout records** on your watch.
- 3. You can view your heart rate chart, maximum heart rate, and average heart rate for each workout on the exercise record screen in the Huawei Health App.

M NOTE

- If you remove your watch during a workout, your watch will stop displaying your heart rate. Measurement will resume when you wear your watch again.
- Your watch can measure your heart rate when you connect it to your phone and start a workout using the Huawei Health app.

Continuous heart rate monitoring

To enable this feature, connect your watch to your phone using the Huawei Health app, and enable **Continuous heart rate monitoring** in the Huawei Health app.

Resting heart rate measurement

Resting heart rate refers to your heart rate when you are awake and in a state of rest, and is a general indicator of your cardiac health.

The best time to measure your resting heart rate is right after you wake up in the morning. As your watch's automatic heart rate measurement measures your heart rate throughout the day, the resting heart rate displayed may not be the same as your morning measurement.

To measure your resting heart rate automatically, enable **Continuous heart rate monitoring** in the Huawei Health app.

□ NOTE

If you disable **Continuous heart rate monitoring** after checking your resting heart rate, the resting heart rate displayed in the Huawei Health app will remain at the last measured value.

3.5 Sleep tracking

Your watch tracks your sleep quality when you wear it while sleeping. It can automatically detect when you fall asleep, wake up, and whether you are in light or deep sleep. You can also view your sleep data in the Huawei Health app after you sync your sleep data with your phone.

You can view sleep data of the current day on your watch. Sleep data history can be viewed in the Huawei Health app.



You can enable **HUAWEI TruSleep[™]** in the Huawei Health app. TruSleep provides you with sleep quality analysis and suggestions to help you understand and improve your sleep quality.

After you enable **HUAWEI TruSleepTM**, your watch will collect comprehensive sleep data to create its analysis. It can detect when you fall asleep, wake up, and whether you are in light, deep, or REM sleep. It will also detect the number of times you wake up and your breathing quality.

3.6 Syncing and sharing your fitness and health data

You can share your fitness and workout data to third-party apps to compete with your friends.

To share your fitness data to a third-party app, open the Huawei Health app, go to Me > Data sharing and select the platform you want to share to. Follow the on-screen instructions specific to each platform.

M NOTE

This feature is available only in certain regions.

4 Messaging assistant

4.1 Incoming call notification

When your watch is connected to your phone and you receive a call, your watch will vibrate and display the caller's number and name.

M NOTE

- The incoming call information displayed on your watch matches the information displayed on your phone. If the caller is unknown, the phone number will be displayed. If you have the number saved in your contacts, the caller's name will be displayed.
- Your watch will not vibrate for incoming calls when **Do not disturb** is enabled.



4.2 Rejecting an incoming call

When you receive an incoming call notification on your watch, you can reject the incoming call by touching **Reject**.

4.3 Messages reminders and content display

Your watch can notify you when a new message appears in your phone's status bar.

To enable this feature, use one of the following methods:

• For Android users: Open the Huawei Health app, go to Me > My devices > Notifications and enable Notifications for apps whose notifications you want to receive.

• For iOS users: Open the Huawei Health app, go to Devices > Notifications management > Message alerts and enable Message alerts. Also enable notifications in your phone Settings for apps whose notifications you want to receive.

You are able to receive alerts on your watch when new app notifications are displayed on your phone status bar.



When you receive a notification, swipe up or down on the watch screen to view message content. A maximum of 10 unread messages can be stored on your watch. If there are more than 10 unread messages, only the latest 10 messages will be displayed.

MOTE

- Your watch can display messages from the following apps: Messaging, Email, Calendar, and social apps.
- If you receive a new message when you are reading another message, your watch will not display the new message instantly. It will display new message after you delete the current message.
- When your watch is in **Do not disturb** or sleep mode, it will still receive notifications but will not alert you. You can swipe right on your watch home screen to view new messages.

4.4 Deleting a message

Swipe right on the screen to delete the current message. You can also touch **Clear All** at the bottom of the message list to delete all unread messages.



- **For Android users:** Messages will be automatically deleted from your watch once read or viewed on your phone.
- **For iOS users:** Messages will be automatically deleted from your watch once read or deleted on your phone.

5 Setting alarms

5.1 Setting a Smart alarm

You can set a Smart alarm for your watch in the Huawei Health app. The watch will wake you up when it detects that you are in light sleep. Waking up from light sleep is easier and leaves you naturally rested.

For Android users:

- 1. Open the Huawei Health app, touch the watch icon in the upper right corner under **Home**, and go to **Alarm** > **Smart alarm**.
- 2. Set the alarm time, Smart wakeup, and repeat cycle.
- 3. Touch $\sqrt{\ }$ in the upper right corner to save your settings.
- 4. Swipe down on the Huawei Health app home screen to sync the alarm to your watch.



For iOS users:

- 1. Open the Huawei Health app and touch **Devices**.
- 2. Touch the watch's Bluetooth name from the device list.

- 3. Go to Alarm > Smart alarm.
- 4. Set the alarm time, Smart wakeup, and repeat cycle.
- Touch Save.
- 6. Swipe down on the Huawei Health app home screen to sync the alarm to your watch.

M NOTE

- When the watch's alarm activates, touch or press the up button to turn off the alarm.

 to snooze for another 10 minutes. Touch or press the up button to turn off the alarm.
- If you perform no operations when the alarm vibrates, it will automatically be turned off if you hit snooze three times.

5.2 Setting an Event alarm

Method 1: Set an Event alarm on your watch

- 1. On the home screen, press the up button and touch **Alarm**, and touch + to add an alarm.
- 2. Set the alarm time and repeat cycle, and touch **OK**.
- 3. Touch the alarm you have set to edit or modify the alarm.

Method 2: Set an Event alarm with the Huawei Health app

For Android users:

- 1. Open the Huawei Health app, and go to **Alarm** > **Event alarms** under **Devices**.
- 2. Set the alarm time, tag, and repeat cycle.
- 3. Touch $\sqrt{\ }$ in the upper right corner to save your settings.
- 4. Swipe down on the Huawei Health app's home screen to ensure the alarm is synced to the watch.



For iOS users:

- Open the Huawei Health app, touch **Devices** and touch the watch's Bluetooth name in the device list.
- 2. Go to Alarm > Event alarm.
- 3. Set the alarm time, tag, and repeat cycle.
- Touch Save
- 5. Swipe down on the Huawei Health app's home screen to ensure the alarm is synced to the watch.

M NOTE

- The Event alarm set on your watch can be synced to the Huawei Health app, and you are able to set at a maximum of five Event alarms.
- The Event alarm will vibrate to remind you at precisely the time you set. If you set a tag and time for the Event alarm, the watch will display the tag. Otherwise, only the time will be displayed.
- When the watch's alarm vibrates, touch the on the screen to snooze for another 10 minutes,
- and touch on the screen or press the up button to turn off the alarm.
 If you perform no operations when the alarm vibrates, it will automatically be turned off if you hit snooze three times.

6 Watch faces

6.1 Changing the watch face

You can change the watch face with any of these methods:

Method 1: Touch and hold the home screen to access the watch face selection menu.



Method 2: On the home screen, press the up button, go to Settings > Display > Watch face, then swipe right or left to choose the face you want to use.



7_{Apps}

7.1 Barometer

Your watch can measure the altitude and atmospheric pressure of your current location.

Press the up button of your watch, then swipe up or down on the screen, and touch **Barometer**. Your watch will display the current altitude and atmospheric pressure as well as a graph showing atmospheric changes during the current day.

Altitude:

Altitude measurement range: -800 to 8800 metres

Atmospheric pressure:

Atmospheric pressure measurement range: 300 to 1100 hPa



7.2 Compass

Need to find your bearings? Your watch can point you in the right direction.

Press the up button on your watch, then swipe up or down on the screen, and touch **Compass**. Move your watch according to the on-screen instructions to complete the calibration process. The compass will then be displayed.



7.3 Stopwatch and Timer

Stopwatch

Press the up button on your watch, swipe up or down on the screen, and touch **Stopwatch**.

Touch to start timing. Touch to reset the stopwatch. Swipe right on the screen to close the stopwatch.

Timer

By default, the watch provides eight countdown timer options: 1 minute, 3 minutes, 5 minutes, 10 minutes, 15 minutes, 30 minutes, 1 hour, and 2 hours.



You can also set a customised timer. Touch **Timer** and touch **Custom** at the bottom of the screen, then set your timer. Touch to start the countdown.

7.4 Flashlight

Light up your surroundings with your watch's flashlight.

Press the up button on your watch, then swipe up or down on the screen, and touch **Flashlight**. Touch the screen to turn off the flashlight. Touch the screen again to turn it on. Swipe left to close **Flashlight**.


7.5 Find phone

Forgot where you left your phone? Locate it with your watch.

Press the up button on your watch and touch **Find phone**, or swipe down on the home screen, and touch **Find Phone**. An animation will display on the screen. If your phone is within Bluetooth range, it will play a ringtone (even in Silent mode) to alert you of its location.

O NOTE

To enable this feature, ensure that the watch is connected to your phone, and the Huawei Health app is running in the background or foreground.





8 Updating and factory reset

8.1 Viewing version information

On your watch's home screen, press the up button, and go to **Settings** > **About**. You can then view your watch's system version.




8.2 Updating your watch and the Huawei Health app

Updates for your watch and the Huawei Health app are released from time to time, bringing user experience improvements. When a new update is available, follow the steps below to update your watch and the Huawei Health app.

Updating your watch

Method 1: Connect your watch to your phone with the Huawei Health app. Open the Huawei Health app, and touch the watch icon in the upper right corner under **Home** (or go to Me > My devices). Touch **Firmware update** and follow the on-screen instructions to update your watch.



Method 2:

- For Android users: Open the Huawei Health app, and touch the watch icon in the upper right corner under Home (or go to Me > My devices) and enable Auto-download update packages over Wi-Fi. When an update is available, a notification will be sent to your watch. Follow the on-screen instructions to update your watch.
- For iOS users: Open the Huawei Health app, touch the profile picture in the upper left corner, touch Settings, and enable Auto-download update packages over Wi-Fi. If an update is available, a notification will be sent to your watch. Follow the on-screen instructions to update your watch.



Updating the Huawei Health app

For Android users: Open the Huawei Health app and go to Me > Check for updates.

For iOS users: Update the Huawei Health app in the App Store.



During an update, your watch will automatically disconnect from Bluetooth. It will reconnect once the update is complete.

8.3 Resetting your watch

You can restore your watch to its factory settings by following the steps below.

NOTE

Resetting your watch will erase all your data.

Method 1: On your watch's home screen, press the up button, and go to **Settings** > **System** > **Reset**.



Method 2: Open the Huawei Health app and touch the device icon in the upper right corner under **Home**, then touch **Restore factory settings**.

8.4 Force restart

Hold the up button for 16 seconds or more to force restart your watch.



8.5 Viewing the Bluetooth name and MAC address

You can view your watch's Bluetooth name and MAC address with these methods:

Method 1: On your watch's home screen, press the up button and go to **Settings** > **About**. The **Device Name** is your watch's Bluetooth name. The 12 alphanumeric characters next to **MAC:** is your watch's MAC address.



Method 2: Your watch's Bluetooth name and MAC address are laser engraved on its back. The Bluetooth name is written as "HUAWEI WATCH GT-XXX". The 12 alphanumeric characters next to **MAC:** is your watch's MAC address.

Method 3:

- 1. Open the Huawei Health app and touch the watch icon in the upper right corner under **Home**. The information next to **Restore factory settings** is your watch's MAC address.
- 2. Go to Me > My devices. The watch's name under My Devices is its current Bluetooth name.

9 Maintenance

9.1 Water and dust resistance

Your watch has water resistance rating of 50 metres under ISO standard 22810:2010. You can wear your watch for water-related activities such as swimming in a pool or ocean. You should not wear your watch for snorkeling, water skiing, diving, or other activities involving deep or high-velocity water. You should not wear your watch to saunas, hot springs, or in a hot shower.













Your watch is resistant to dust in many typical situations (such as in a living room or office). It is not suitable for use in extreme dust environments.

MOTE

- The leather strap is not water resistant and should not be exposed to liquids. Switch to a silicone rubber strap when you need to participate in water-related activities.
- If your watch's screen is wet, wipe it dry before use.
- Your watch's water resistance is not permanent and may wear off over time.

9.2 Cleaning and care

Cleaning your watch

You should keep your watch and wrist clean and dry. To clean the watch, wipe the watch with a soft cloth. It is also recommended that you clean dust from its gaps regularly.

Maintaining the watch face

Your watch's face is made of scratch-resistant glass and ceramic with a high degree of hardness. It can withstand normal wear and tear, but you should not drop it, or expose it to excessive force or sharp objects such as knives and stones.

Light-colour strap maintenance

To prevent discolouration, avoid letting your light-colour strap contact dark clothing.

If your light-colour strap gets dirty, dip a soft brush in clean water and use it to gently wipe the strap dry.

For stubborn stains, try rubbing a small amount of toothpaste onto the stained area.

Leather strap maintenance

- Store your leather strap in a well-ventilated and dry place when you are not using it. If the strap gets dirty or wet, use a clean, soft cotton cloth to wipe the water or dirt off the strap, then let it air dry in a well-ventilated and cool location. When the strap becomes dry again, apply a layer of leather polish to its surface.
- Do not dry your leather strap by placing it in direct sunlight or with heating appliances such as microwaves or hairdryers. Doing so may cause your strap to expand or shrink.
- Do not expose your leather strap to rough or sharp objects.
- Do not contort the strap for extended periods. Doing so may damage your strap.
- Keep the strap away from flammable, acidic, and alkaline materials.
- Do not wear your leather strap too tightly or bend it excessively. Doing so may damage your strap.
- Do not punch extra holes in your leather strap. Doing so will damage the strap's protective layer and expose the raw leather to damage.


9.3 Adjusting or replacing the strap

Adjusting the strap

Insert the strap into the T-buckle, adjust its length until it is comfortable on your wrist, and then secure it by inserting the T-buckle's prong into a strap hole.

Replacing the strap

Unlock the spring pin and remove your current strap. Unlock the spring pin, insert your new strap, and then release the spring pin to attach it.



10 FAQs

About This Chapter

- 10.1 How do I extend the standby time of my watch
- 10.2 Why is the step count between the Huawei Health app and my watch inconsistent
- 10.3 Which factors can affect heart rate monitoring
- 10.4 What should I do if the exercise data on my watch can't be synced to the Huawei Health app
- 10.5 What should I do if I can't sync sleep data to the Huawei Health app

10.1 How do I extend the standby time of my watch

To extend the standby time of your watch, perform the following steps:

Disable the following functions in the Huawei Health app when you are not using them: TruSleep, continuous heart rate measurement, and notification management.

10.2 Why is the step count between the Huawei Health app and my watch inconsistent

To maximise step count accuracy, the Huawei Health app integrates the step count from both your watch and your phone, considering that the two devices may not always be together throughout the day.

For example, if you are only carrying your phone and not wearing your watch, your steps during that period of time will only be recorded by your phone. In this case, the step count between the Huawei Health app and your watch will be inconsistent.

10.3 Which factors can affect heart rate monitoring

Heart rate monitoring can be affected by various environmental and situational factors. If you find that your heart rate measurement fails during use, or the data is incorrect, please refer to the following:

- If your watch is loosely worn or is not well-attached to your wrist, it will not be able to obtain data through the fluctuations of your blood flow. In this case, ensure that your watch is well-attached to your wrist, and that the watch face is facing upwards. It is recommended that you wear it slightly above your wrist joint for maximum comfort. Ensure that your watch is well-attached to your wrist during exercises to prevent it from slipping due to excess movements.
- Ensure that the back of your watch is clean, dry, and free of obstruction from foreign objects. Excessive sweating during exercises can cause your watch to slip or obstruct the light path, resulting in an inaccurate measurement. In this case, detach your watch and wipe off any sweat or smudges, then reattach it to your wrist.
- Ensure that the back of your watch is clean, dry, and free of obstruction from foreign objects. Excessive sweating during exercises can cause your watch to slip or obstruct the light path, resulting in an inaccurate measurement. In this case, detach your watch and wipe off any sweat or smudges, then reattach it to your wrist.
- Ensure that the measuring area of your skin is free of scars, tattoos, or excessive hair that may affect the heart rate measurement.
- Extreme low temperatures may also alter the blood flow of the human body and cause the heart rate measurement to be inaccurate. In this case, it is recommended that you initiate a heart rate measurement after warming up from low temperatures.
- Heart rates are much easier to measure during regular movement exercises (such as run, walk, and cycle) compared to irregular movement exercises (such as basketball and free activities), while wrist strength exercises (such as weightlifting) may even complicate the process. Please refer to the exercise menu on your watch to engage in the corresponding type of exercise.
- If you find that your heart rate is abnormal during an exercise, keep your watch facing upwards and stand still for approximately 10 to 15 seconds to check whether your heart rate returns to normal. If your heart rate cannot be measured after multiple attempts, it is recommended that you restart your watch and try again.

10.4 What should I do if the exercise data on my watch can't be synced to the Huawei Health app

If the exercise data on your watch cannot be synced to the Huawei Health app, please refer to the following:

- 1. Ensure that your watch is successfully paired with your phone.
- 2. Swipe down on the Huawei Health app home screen to sync the data from your watch.

If the issue persists, it is recommended that you re-enable the Bluetooth on your phone, then reopen the Huawei Health app and try again.

10.5 What should I do if I can't sync sleep data to the Huawei Health app

Touch the up button on your watch to enter the apps list. Touch **Sleep** to view your sleep duration. If your sleep duration is 0 then this means that your watch has not recorded any sleep data. Ensure you are wearing your watch correctly.

If you constantly move your wrist when you sleep, this may cause your watch to assume that you are not sleeping. This issue will also occur when you are sleeping in a moving object such as a car or train.

If your watch runs out of battery power and powers off when you are sleeping, your sleep data will be lost.

If TruSleep is enabled on your watch, perform the following to troubleshoot:

- 1. Huawei phone users: Ensure that your watch is connected to the Huawei Health app when syncing sleep data.
 - If the sleep data cannot be synced, it is recommended that you open the Huawei Health app, swipe down on the app home screen and manually refresh.
 - It is recommended that you add the Huawei Health app to the list of protected background apps on your phone to prevent it from being automatically cleared by your phone system.
- 2. Non-Huawei phone users: Ensure that your watch is connected to the Huawei Health app and Huawei Mobile Services app when syncing sleep data.
 - If the sleep data cannot be synced, it is recommended that you open the aforementioned apps, swipe down on the home screen of the Huawei Health app and manually refresh.
 - It is recommended that you add both aforementioned apps to the list of protected background apps on your phone to prevent them from being automatically cleared by your phone system.
- iPhone users: Ensure that your watch is connected to the Huawei Health app when syncing sleep data.
 - If the sleep data cannot be synced, it is recommended that you open the Huawei Health app, swipe down on the app home screen and manually refresh.

If the issue persists, try disabling and re-enabling Bluetooth on your phone. Ensure that there is a working connection between your watch and the Huawei Health app and then swipe down on the home screen to re-sync the data.