

SWITCH	PROBLEM	INPUT	DISPLAY
F	Set currency rate=12	$\overline{ONC}$ 1 2 SET	0. 12. € 12.
F	Exchange 4235(¥)=? (€)	4 2 3 5 €	4235. € 352.92
F	Exchange 4567(€)=? (¥)	4 5 6 7 ¥	4567. ¥ 54804.00
F	Currency rate review	$\overline{ONC}$ SET €	0. € 12.
F	2+6-7=	$\overline{ONC}$ 2 + 6 - 7 =	0. 1.
5/4 A	0.02+0.03-0.01=	2 + 3 - 1 =	0.04
↑ 4	-2.7 × 9 ÷ 7 =	2 . 7 X 9 ÷ 7 =	-3.4715
↓ 3	4 × (5+6) ÷ 3 =	5 + 6 X 4 ÷ 3 =	14.666
F	2 ÷ 3 =	2 ÷ 4 CE 3 =	0.666666666666
F	BACKSPACE	→ → →	0.6666666666
↓ 0	2.2+3=	2 . 2 + 3 =	5.
	4.6+3=	4 . 6 =	7.
5/4 2	2.465-5.73=	2 . 4 6 5 - 5 . 7 3 =	-3.27
	9.7-5.73=	9 . 7 =	3.97
↑ A	2.7 × 1.26=	2 . 7 X 1 . 2 6 =	3.41
	2.7 × 3.27=	3 . 2 7 =	8.83
5/4 4	7 ÷ 6 =	7 ÷ 6 =	1.1667
	8 ÷ 6 =	8 =	1.3333
F	2+3+3=	2 + 3 = =	8.
	6-2-2=	6 - 2 = =	2.
	2³=	2 X = =	8.
	1 ÷ 5 ÷ 5 =	5 ÷ = =	0.04
F	20 × 25% =	2 0 X 2 5 %	5.
	5 ÷ 20% =	5 ÷ 2 0 %	25.
	20 × (1+15%) =	2 0 + 1 5 %	23.
	20 × (1-20%) =	2 0 - 2 0 %	16.
F	100 ÷ (1-20%) =	1 0 0 ÷ 2 0 MU	125.
	100 ÷ (1-20%) - 100 =	1 0 0 ÷ 2 0 MU MU	25.
F	2 × 3 = 6	2 X 3 M+	M 6.
	-) 3 × 4 = 12	3 X 4 M-	M 12.
	+ ) 4 × 5 = 20	4 X 5 M+	M 20.
	14	MR	M 14.
		MC	14.